

TUNGSTEN CARBIDE GRIT EDGE BAND SAW BLADES

EXTENDING THE LIFE OF YOUR BLADES

Toothed band saw blades can be run in only one direction because the cutting surface on the teeth face only one way. M. K. Morse Tungsten Carbide Grit (TCG) blades have no teeth. The TCG blades have either an interrupted or continuous line of tungsten carbide grit bonded to the cutting edge. As a result, these blades can be run in either direction.

Tip: Use continuous carbide grit blades for interrupted cuts and gulleted carbide grit for solids.

To extend the life of your TCG blades try this:

- *After a period of use, say several days, take the blade off the machine*
- *Flip the blade inside-out*
- *Put the blade back on the machine*

By doing this, the cutting facets on the carbide will face in the opposite direction exposing new sharp facets to do the work. You can extend the life of your blade while getting that new TCG blade on order from your local M. K. Morse distributor!

Top Applications

Composites

Hardened Steel

Foamed Glass

Fiberglass

Cast Iron

Ceramics

Graphite

Cement and Concrete

Cable and Wire Rope

Tires and Wire Reinforced Rubber